



 Ref.:
 EO

 Issue:
 1.6

 Date:
 20/

 Page:
 1 /

EOCFI-FTD-004 1.6 20/12/2011 1 / 11

# CRYOSAT-2: TRANSPONDER PASS TOOLS - FILE TRANSFER DOCUMENT

# 1. INTRODUCTION

This is the File Transfer Document for the executable routines that compute ground-track points for a given set of visibility time windows over a zone or transponder location as well as information associated to the point of closest approach within each pass over a transponder.

### 1.1 Change History

lssue	Change Description
1.2	First issue of public distribution
1.3	Executable routines built using EE CFI v3.7.3
	WINDOWS executables added to the package
1.4	MPL_ORBREF file: Use orbit state vectors instead of orbit
	change parameters
	Use Cryosat-2 On Board attitude law instead of
	theoretical Local Normal + Yaw Steering in the
	satellite/ground minimum distance executables
1.5	Discard last two orbits in POF (related to EOCFI-AN-449)
	Added auxiliary DLLs for Windows executables
1.6	Executable routines built using EO CFI v3.7.4 (anomaly
	EOCFI-AN-449 has been solved)
	Input Swath Definition File changed: Cryosat-2 On Board
	attitude law instead of theoretical Local Normal for zone
	intersection calculation

# 1.2 <u>Distribution List</u>

Project/Unit	Name	Project/Unit	Name	Project/Unit	Name

# 2. ARCHIVE CONTENT

The following archive file has been delivered (generated with the zip utility): EOCFI-FTD-004\_1\_6.zip

The archive has the following MD5 checksum: aa2092881be23ea625ecd0a42a96ba4a

The archive contains the following files:

```
Transponder_Pass_Routines_v1_6/INPUT/CS_OPER_MPL_ORBPRE_20100517T000000_20100617T000000_0001.EEF
Transponder_Pass_Routines_v1_6/INPUT/SDF_ORBIT.CS
Transponder_Pass_Routines_v1_6/INPUT/input_data_transponder.txt
Transponder_Pass_Routines_v1_6/INPUT/zones.dbf
Transponder_Pass_Routines_v1_6/LINUX/transponder_min_ground_distance
Transponder_Pass_Routines_v1_6/LINUX/transponder_min_satellite_distance
Transponder_Pass_Routines_v1_6/LINUX/transponder_min_ground_distance
Transponder_Pass_Routines_v1_6/LINUX/transponder_min_ground_distance
Transponder_Pass_Routines_v1_6/LINUX/zone_intersection_lon_lat
Transponder_Pass_Routines_v1_6/MACINTEL/transponder_min_ground_distance
Transponder_Pass_Routines_v1_6/MACINTEL/transponder_min_satellite_distance
Transponder_Pass_Routines_v1_6/OUTPUT/output_data_LLF_CRYOSAT.txt
Transponder_Pass_Routines_v1_6/OUTPUT/output_data_TRANSPONDER_CRYOSAT_min_ground_distance.txt
Transponder_Pass_Routines_v1_6/OUTPUT/output_data_TRANSPONDER_CRYOSAT_min_satellite_distance.txt
Transponder_Pass_Routines_v1_6/OUTPUT/output_data_TRANSPONDER_CRYOSAT_min_satellite_distance.txt
Transponder_Pass_Routines_v1_6/OUTPUT/output_data_TRANSPONDER_CRYOSAT_min_satellite_distance.txt
Transponder_Pass_Routines_v1_6/OUTPUT/output_data_TRANSPONDER_CRYOSAT_min_satellite_distance.txt
```





 Ref.:
 EOCFI-FTD-004

 Issue:
 1.6

 Date:
 20/12/2011

 Page:
 2 / 11

Transponder\_Pass\_Routines\_v1\_6/WINDOWS/iconv.dll Transponder\_Pass\_Routines\_v1\_6/WINDOWS/libxml2.dll Transponder\_Pass\_Routines\_v1\_6/WINDOWS/pthreadVC2.dll Transponder\_Pass\_Routines\_v1\_6/WINDOWS/transponder\_min\_ground\_distance.exe Transponder\_Pass\_Routines\_v1\_6/WINDOWS/transponder\_min\_satellite\_distance.exe Transponder\_Pass\_Routines\_v1\_6/WINDOWS/zlib1.dll Transponder\_Pass\_Routines\_v1\_6/WINDOWS/zone\_intersection\_lon\_lat.exe

# 3. ARCHIVE CONTENT DESCRIPTION

File	Description
INPUT/	Cryosat-2 Predicted Orbit File
CS_OPER_MPL_ORBPRE_20100517T000000_20100617T000000_0001.EEF	example (input)
INPUT/SDF_ORBIT.CS	Cryosat-2 Swath Definition File
	(input)
INPUT/input data transponder.txt	Input configuration file for the
	executables
	transponder min around distance
	transponder_min_stallite_distance
TNDUM/input data sono tut	transponder_min_satellite_distance
INPOT/input_data_zone.txt	Input configuration file for the
	executable
	zone_intersection_lon_lat
INPUT/zones.dbf	Zone Database File example (input)
LINUX/transponder_min_ground_distance	Executable tools for Linux
LINUX/transponder_min_satellite_distance	
LINUX/zone_intersection_lon_lat	
MACINTEL/transponder_min_ground_distance	Executable tools for Mac Intel
MACINTEL/transponder_min_satellite_distance	
MACINTEL/zone_intersection_lon_lat	
OUTPUT/output_data_LLF_CRYOSAT.txt	Output file generated by the
	executable
	zone_intersection_lon_lat
OUTPUT/output_data_TRANSPONDER_CRYOSAT_min_ground_distance.txt	Output file generated by the
	executable
	transponder_min_ground_distance
OUTPUT/output_data_TRANSPONDER_CRYOSAT_min_satellite_distance.txt	Output file generated by the
	executable
	transponder min satellite distance
README.txt	Quick reference
WINDOWS/transponder_min_ground_distance.exe	Executable tools for Windows
WINDOWS/transponder_min_satellite_distance.exe	
WINDOWS/zone_intersection_lon_lat.exe	
WINDOWS/iconv.dll	Auxiliary libraries for Windows
WINDOWS/libxml2.dll	
WINDOWS/pthreadVC2.dll	
WINDOWS/zlib1.dll	

# 4. INSTALLATION

The archive can be expanded with the command unzip (in Linux/Mac Intel) or with Winzip / 7-zip (in MS Windows).

# 5. <u>USAGE</u>

# 5.1 <u>Executable program zone\_intersection\_lon\_lat</u>

For a requested UTC time interval, the executable program zone\_intersection\_lon\_lat computes the ground-



track longitude and latitude pairs (with a given time step) corresponding to the passes obtained over a zone or transponder location.

### 5.1.1 Input configuration file description input\_data\_zone.txt

The executable program *zone\_intersection\_lon\_lat* expects as input a configuration file named *input\_data\_zone.txt*. Note that the configuration file has to be placed in the same folder where the executable routine is located.

The configuration file *input\_data\_zone.txt* contains the following input parameters (provided in the order in which they have to be supplied):

INPUT PARAMETERS	Definition	Value
Satellite ID	Satellite identifier	CRYOSAT
Predicted or Restituted Orbit Filename	Filename (it may include the path to the file) of the Predicted or Restituted Orbit File	Given by the user
Time Interval Type Flag	Flag to indicate the type of time interval to use for the calculation	0=orbit range 1=UTC time range
Start Orbit	Start orbit	Given by the user
or UTC Start Time	or UTC start time (in format YYYY-MM- DD_HH:mm:ss.sssss) of the	
	time interval	
Stop Orbit or UTC Stop Time	Stop orbit or UTC stop time (in format YYYY-MM- DD_HH:mm:ss.sssss) of the time interval	Given by the user
Time Step [s]	Time step (in seconds) for the computation of intermediate points	Given by the user
Swath Definition Filename	Filename (it may include the path to the file) of the swath definition file.	SDF_ORBIT.CS
Zone Database Filename	Filename (it may include the path to the file) of the zone database file.	zones.dbf Two example zones are included.
Zone ID	Zone identifier	Given by the user. It has to match the value of one of the <zone_id> tags in Zone Database File.</zone_id>

# 5.1.2 Output file description *output\_data\_LLF\_CRYOSAT.txt*

The executable program *zone\_intersection\_lon\_lat* generates as output a file *output\_data\_LLF\_CRYOSAT.txt*.

The output file includes comments (starting with the symbol #) describing its contents. Note that it is created in the same folder where the executable routine is located.



# 5.1.3 Example

#### 5.1.3.1 Input configuration file

The input configuration file and the executable tool have to be contained in the same directory.

An example of input configuration file *input\_data\_zone.txt*, with UTC start/stop times given as time interval is provided below:

CRYOSAT

```
./AUX_FILES/CS_OPER_MPL_ORBPRE_20100517T000000_20100617T000000_0001.EEF
1
2010-05-21_00:00:00.000000
2010-05-26_00:00:00.000000
1.0
./AUX_FILES/SDF_ORBIT.CS
./AUX_FILES/zones.dbf
cryosat_transponder
```

An example of input configuration file *input\_data\_zone.txt*, with orbit start/stop given as time interval is provided below:

```
CRYOSAT
./AUX_FILES/CS_OPER_MPL_ORBPRE_20100517T000000_20100617T000000_0001.EEF
0
616
689
1.0
./AUX_FILES/SDF_ORBIT.CS
./AUX_FILES/zones.dbf
cryosat_transponder
```

In both examples, the Predicted Orbit file, the Swath Definition File and the Zone Database file are contained in a directory AUX\_FILES/

#### 5.1.3.2 Running the executable

The executable program can be called in the following way:

- From Linux/Mac shell

```
./zone_intersection_lon_lat
```

- From Windows command prompt window

```
zone_intersection_lon_lat.exe
```

The executable program shows the following messages:

```
Input data set by the user:
Satellite: CRYOSAT
Orbit File: ./AUX_FILES/CS_OPER_MPL_ORBPRE_20100517T000000_20100617T000000_0001.EEF
Start Time: 2010-05-21_00:00:00.000000
Stop Time: 2010-05-26_00:00:00.000000
Time Step: 1.000000 <>>
SDF filename: ./AUX_FILES/SDF_ORBIT.CS
Zone filename: ./AUX_FILES/zones.dbf
Zone ID: cryosat_transponder
Output Filename: output data LLF_CRYOSAT.txt
```





 Ref.:
 EOCFI-FTD-004

 Issue:
 1.6

 Date:
 20/12/2011

 Page:
 5 / 11

TIME INITIALIZATION: POF

ORBIT INITIALIZATION: POF

CALCULATION OF ZONE INTERSECTION TIME SEGMENTS

```
Inputs:
  Start/Stop Absolute Orbit: 615 / 688
Outputs:
  Number of segments: 2
   Segments: Start (Orbit, seconds, microseconds) -- Stop (Orbit, seconds, microseconds)
             ( 654, 1676, 561622) -- ( 654, 1678, 205424)
             ( 675, 1292, 201161) -- ( 675, 1293, 949962)
CALCULATION OF INTERMEDIATE POINTS, VISIBILITY SEGMENT #0
Inputs:
  Requested Orbit, Second, Microsecond: 654 1676 561622
Outputs:
  -
Pt #0:
           long = 15.342628, lat = 78.283220
Inputs:
  Requested Orbit, Second, Microsecond: 654 1677 561622
Outputs:
  Pt #0:
            long = 15.287197, lat = 78.223714
CALCULATION OF INTERMEDIATE POINTS, VISIBILITY SEGMENT #1
Inputs:
  Requested Orbit, Second, Microsecond: 675 1292 201167
Outputs:
          long = 15.486070, lat = 78.180189
  Pt #0:
Inputs:
   Requested Orbit, Second, Microsecond: 675 1293 201167
Outputs:
  Pt #0:
           long = 15.431024, lat = 78.239674
Output file created successfully in output data LLF CRYOSAT.txt
```

#### 5.1.3.3 Output file

The output file *output\_data\_LLF\_CRYOSAT.txt* is created:

# Generated with executable tool zone intersection lon lat v1.6 # Data Block # Instrument: ORBIT # Predicted orbit file: ./AUX FILES/CS OPER MPL ORBPRE 20100517T000000 20100617T000000 0001.EEF # 1 Number of visibility segments | Number of points per instantaneous swath 2 1 # 2 Index of visibility segment | Orbit number start | Seconds since ANX start | UTC time start | {Longitude [deg] Latitude [deg],..} | Orbit number stop | Seconds since ANX stop | UTC time stop | {Longitude [deg] Latitude [deg],...}  $\bar{0}$  654 +1676.561622 20100523\_152406165745 +015.342628 +078.283220 654 +1678.205424 20100523 152407809547 +015.251802 +078.185399 # 3 Time step [s] | Number of intermediate points in visibility segment +001.000000 3 # 4 Index of intermediate point | Orbit number | Seconds since ANX | UTC time | {Longitude [deg] Latitude [deg],..} 0 654 +1676.561622 20100523 152406165745 +015.342628 +078.283220 1 654 +1677.561622 20100523 152407165745 +015.287197 +078.223714

2 654 +1678.205424 20100523 152407809547 +015.251802 +078.185399



# 2 Index of visibility segment | Orbit number start | Seconds since ANX start | UTC time start |
{Longitude [deg] Latitude [deg],...} | Orbit number stop | Seconds since ANX stop | UTC time stop |
{Longitude [deg] Latitude [deg],...}

1 675 +1292.201161 20100525\_020122355555 +015.486070 +078.180188 675 +1293.949962

20100525\_020124104355 +015.389445 +078.284210

# 3 Time step [s] | Number of intermediate points in visibility segment +001.000000 3

# 4 Index of intermediate point | Orbit number | Seconds since ANX | UTC time | {Longitude [deg]
Latitude [deg],..}

0 675 +1292.201167 20100525\_020122355555 +015.486070 +078.180189

 $1 \ 675 \ +1293.201167 \ 20100525 \ 020123355555 \ +015.431024 \ +078.239674$ 

2 675 +1293.949962 20100525\_020124104355 +015.389445 +078.284210

# End Data\_Block

### 5.2 <u>Executable program transponder\_min\_satellite\_distance</u>

For a requested UTC time interval, the executable program *transponder\_min\_satellite\_distance* computes

- the time of closest approach from satellite to transponder (in orbit relative time and UTC)
- the minimum distance between the satellite and the transponder

- the incidence angle of the line of sight with the ellipsoid normal at the time of closest approach

- the longitude and latitude of the sub-satellite point at the time of closest approach

corresponding to the passes obtained over a transponder location.

### 5.2.1 Input configuration file description input\_data\_transponder.txt

The executable program *transponder\_min\_satellite\_distance* expects as input a configuration file named *input\_data\_transponder.txt*. Note that the configuration file has to be placed in the same folder where the executable routine is located.

The configuration file *input\_data\_transponder.txt* contains the following input parameters (provided in the order in which they have to be supplied):

INPUT PARAMETERS	Definition	Value
Satellite ID	Satellite identifier	CRYOSAT
Predicted or Restituted Orbit Filename	Filename (it may include	Given by the user
	the path to the file) of the	
	Predicted or Restituted	
	Orbit File	
Time Interval Type Flag	Flag to indicate the type of	0=orbit range
	time interval to use for the	1=UTC time range
	calculation	
Start Orbit	Start orbit	Given by the user
or	or	
UTC Start Time	UTC start time (in format	
	YYYY-MM-	
	DD_HH:mm:ss.sssss) of the	
	time interval	
Stop Orbit	Stop orbit	Given by the user
or	or	
UTC Stop Time	UTC stop time (in format	
	YYYY-MM-	
	DD_HH:mm:ss.sssss) of the	
	time interval	
Time Step [s]	Time step (in seconds) used	0.001
	to compute the minimum	
	distance	
Swath Definition Filename	Filename (it may include	SDF_ORBIT.CS
	the path to the file) of the	
	swath definition file.	



Transponder Longitude [deg]	Transponder geocentric longitude (in degrees)	Given by the user For the Svalbard Transponder: +015_393777
Transponder Latitude [deg]	Transponder geodetic latitude (in degrees)	Given by the user For the Svalbard Transponder: +078.230514
Transponder Diameter [m]	Diameter of a circular zone with center the transponder location (in meters)	Given by the user 15000.0
Transponder Altitude [m]	Transponder geodetic altitude (in meters)	Given by the user For the Svalbard Transponder: 487.96

# 5.2.2 Output file description output\_data\_TRANSPONDER\_CRYOSAT\_min\_satellite\_distance.txt

The executable program transponder\_min\_satellite\_distance generates as output a file output\_data\_TRANSPONDER\_CRYOSAT\_min\_satellite\_distance.txt. The output file includes comments (starting with the symbol #) describing its contents. Note that it is created in the same folder where the executable routine is located.

# 5.2.3 Example

#### 5.2.3.1 Input configuration file

The input configuration file and the executable tool have to be contained in the same directory.

An example of input configuration file *input\_data\_transponder.txt*, with UTC start/stop times given as time interval is provided below:

```
CRYOSAT

./AUX_FILES/CS_OPER_MPL_ORBPRE_20100517T000000_20100617T000000_0001.EEF

1

2010-05-21_00:00:00.000000

2010-05-26_00:00:00.000000

0.001

./AUX_FILES/SDF_ORBIT.CS

+015.393777

+078.230514

15000.0

487.96
```

An example of input configuration file *input\_data\_transponder.txt*, with orbit start/stop given as time interval is provided below:

```
CRYOSAT

./AUX_FILES/CS_OPER_MPL_ORBPRE_20100517T000000_20100617T000000_0001.EEF

0

616

689

0.001

./AUX_FILES/SDF_ORBIT.CS
+015.393777
+078.230514

15000.0

487.96
```



In both examples, the Predicted Orbit file and the Swath Definition File are contained in a directory AUX\_FILES/

# 5.2.3.2 Running the executable

The executable program can be called in the following way:

```
- From Linux/Mac shell
```

./transponder\_min\_satellite\_distance

- From Windows command prompt window

transponder\_min\_satellite\_distance.exe

The executable program shows the following messages:

```
Input data set by the user:
Satellite: CRYOSAT
Orbit File: ./AUX FILES/CS OPER MPL ORBPRE 20100517T000000 20100617T000000 0001.EEF
Start Time: 2010-05-21_00:00:00.000000
Stop Time: 2010-05-26_00:00:00.000000
Time Step: 0.001000 <s>
SDF filename: ./AUX_FILES/SDF_ORBIT.CS
Transponder Longitude: 15.393777 <deg>
Transponder Latitude: 78.230514 <deg>
Transponder Diameter: 15000.000000< m>
Transponder Altitude: 487.960000< m>
Output Filename: output data TRANSPONDER CRYOSAT min satellite distance.txt
TIME INITIALIZATION: POF
ORBIT INITIALIZATION: POF
CALCULATION OF ZONE INTERSECTION TIME SEGMENTS
Inputs:
   Start/Stop Absolute Orbit: 615 / 688
Outputs:
   Number of segments: 2
   Segments: Start (Orbit, seconds, microseconds) -- Stop (Orbit, seconds, microseconds)
( 654, 1676, 325727) -- ( 654, 1678, 442129)
( 675, 1291, 978018) -- ( 675, 1294, 173176)
CALCULATION OF MINIMUM DISTANCE, VISIBILITY SEGMENT #0
CALCULATION OF MINIMUM DISTANCE, VISIBILITY SEGMENT #1
```

Output file created successfully in output\_data\_TRANSPONDER\_CRYOSAT\_min\_satellite\_distance.txt

#### 5.2.3.3 Output file

The output file *output\_data\_TRANSPONDER\_CRYOSAT\_min\_satellite\_distance.txt* is created:



- 0 654 +1676.325462 20100523\_152405929585 654 +1678.441896 20100523\_152408046019
- # 302 Minimum distance from satellite to transponder

# 303 Orbit number | Seconds since ANX | UTC time | Minimum distance [m] | LOS incidence angle (measured from local normal) [deg] | SSP Longitude [deg] | SSP Latitude [deg]

654 +1677.520478 20100523\_152407124601 +00721433.822799 +000.214100 +015.289606 +078.226167 # 301 Index of visibility segment | Orbit number start | Seconds since ANX start | UTC time start Orbit number stop | Seconds since ANX stop | UTC time stop

- 1 675 +1291.978227 20100525 020122132621 675 +1294.173398 20100525 020124327791
- # 302 Minimum distance from satellite to transponder

# 303 Orbit number | Seconds since ANX | UTC time | Minimum distance [m] | LOS incidence angle

(measured from local normal) [deg] | SSP Longitude [deg] | SSP Latitude [deg]

675 +1293.087248 20100525\_020123241636 +00723032.293449 +000.090153 +015.437006 +078.232969 # End Data\_Block

#### 5.3 <u>Executable program transponder\_min\_ground\_distance</u>

For a requested UTC time interval, the executable program *transponder\_min\_ground\_distance* computes

- the time of closest approach from ground-track to transponder (in orbit relative time and UTC)
- the minimum distance between the ground-track and the transponder
- the incidence angle of the line of sight with the ellipsoid normal at the time of closest approach
- the longitude and latitude of the ground-track point of closest approach

corresponding to the passes obtained over a transponder location.

#### 5.3.1 Input configuration file description input\_data\_transponder.txt

The executable program *transponder\_min\_ground\_distance* expects as input a configuration file named *input\_data\_transponder.txt*. Note that the configuration file has to be placed in the same folder where the executable routine is located.

The configuration file *input\_data\_transponder.txt* has been already described in Section 5.2.1.

#### 5.3.2 Output file description

#### output\_data\_TRANSPONDER\_CRYOSAT\_min\_ground\_distance.txt

The executable program transponder\_min\_ground\_distance generates as output a file output\_data\_TRANSPONDER\_CRYOSAT\_min\_ground\_distance.txt. The output file includes comments (starting with the symbol #) describing its contents. Note that it is created in the same folder where the executable routine is located.

#### 5.3.3 Example

#### 5.3.3.1 Input configuration file

The input configuration file and the executable tool have to be contained in the same directory.

Examples of input configuration files input\_data\_transponder.txt are already given in Section 5.2.3.1

#### 5.3.3.2 Running the executable

The executable program can be called in the following way:





 Ref.:
 EOCFI-FTD-004

 Issue:
 1.6

 Date:
 20/12/2011

 Page:
 10 / 11

#### - From Linux/Mac shell

./transponder\_min\_ground\_distance

- From Windows command prompt window

transponder\_min\_ground\_distance.exe

The executable program shows the following messages:

```
Input data set by the user:
Satellite: CRYOSAT
Orbit File: ./AUX FILES/CS OPER MPL ORBPRE 20100517T000000 20100617T000000 0001.EEF
Start Time: 2010-05-21_00:00:00.000000
Stop Time: 2010-05-26_00:00:00.000000
Time Step: 0.001000 <s>
SDF filename: ./AUX FILES/SDF ORBIT.CS
Transponder Longitude: 15.393777 <deg>
Transponder Latitude: 78.230514 <deg>
Transponder Diameter: 15000.000000< m>
Output Filename: output data TRANSPONDER CRYOSAT min ground distance.txt
TIME INITIALIZATION: POF
ORBIT INITIALIZATION: POF
CALCULATION OF ZONE INTERSECTION TIME SEGMENTS
Inputs:
   Start/Stop Absolute Orbit: 615 / 688
Outputs:
   Number of segments: 2
   Segments: Start (Orbit, seconds, microseconds) -- Stop (Orbit, seconds, microseconds)
               ( 654, 1676, 325727) -- ( 654, 1678, 442129)
( 675, 1291, 978018) -- ( 675, 1294, 173176)
CALCULATION OF MINIMUM DISTANCE, VISIBILITY SEGMENT #0
```

CALCULATION OF MINIMUM DISTANCE, VISIBILITY SEGMENT #1

Output file created successfully in output data TRANSPONDER CRYOSAT min ground distance.txt

#### 5.3.3.3 Output file

The output file *output\_data\_TRANSPONDER\_CRYOSAT\_min\_ground\_distance.txt* is created:

# Generated with executable tool transponder\_min\_ground\_distance v1.6
# Data\_Block
# Instrument: ORBIT
# Predicted orbit file: ./CS\_OPER\_MPL\_ORBPRE\_20100517T000000\_20100617T000000\_0001.EEF
# Transponder location: LON =+015.393777 [deg] LAT =+078.230514 [deg]
# Transponder diameter: 15000.000000 [m]
# 400 Number of visibility segments
2
# 401 Index of visibility segment | Orbit number start | Seconds since ANX start | UTC time start |
Orbit number stop | Seconds since ANX stop | UTC time stop
0 654 +1676.325727 20100523\_152405929850 654 +1678.442129 20100523\_152408046252
# 402 Minimum distance from ground-track to transponder





 Ref.:
 EOCFI-FTD-004

 Issue:
 1.6

 Date:
 20/12/2011

 Page:
 11 / 11

# 403 Orbit number | Seconds since ANX | UTC time | Minimum distance [m] | LOS incidence angle (measured from local normal) [deg] | SSP Longitude [deg] | SSP Latitude [deg] 654 +1677.384741 20100523\_152406988864 +00002240.721068 +000.197901 +015.297111 +078.234245 # 401 Index of visibility segment | Orbit number start | Seconds since ANX start | UTC time start | Orbit number stop | Seconds since ANX stop | UTC time stop

1 675 +1291.978018 20100525\_020122132412 675 +1294.173176 20100525\_020124327569

# 402 Minimum distance from ground-track to transponder

# 403 Orbit number | Seconds since ANX | UTC time | Minimum distance [m] | LOS incidence angle (measured from local normal) [deg] | SSP Longitude [deg] | SSP Latitude [deg] 675 +1293.075039 20100525\_020123229427 +00001018.508056 +000.089776 +015.437681 +078.232243

# End Data\_Block